

EZ Fabriccoat

- Excellent UV Protection
- Hides stains, fading and UV damage
- Coating will not rub off, crack or peel
- Refinishes carpets, vinyl seats and panels and PVC inflatables



FLEXIBLE MARINE FABRIC REFINISHER

EZ Fabriccoat™ is a flexible coating that refinishes marine vinyl seats, panels, wrapped dashboards, carpets, PVC tubes, simulated leather and other marine fabric materials.

This specially formulated flexible coating provides excellent adhesion that will not rub off, crack or peel.

This high-grade marine formula will hide stains, fading and UV damage while providing strong UV protection from the sun's powerful rays. EZ Fabriccoat™ comes in 6 popular colors and finishes.



GLOSS BLACK
3001



FLAT BLACK
3002



GLOSS WHITE
3003



SATIN DARK KHAKI
3004



SATIN GRAY
3005



SATIN DARK GRAY
3006

Note: Color differences may occur between actual color chips shown.

TECHNICAL INFORMATION

VEHICLE TYPE: Acrylic Modified Vinyl Resin Solution

FINISH: Gloss or Satin (depending on color)

COMPONENTS: 1

CURING MECHANISM: Solvent Release

FILL WEIGHT: 12 ounces

COVERAGE: 12 ft²/spray can for 1 coat

MIR: 1.45 grams/liter

FLASH POINT: -150°F

APPLICATION METHOD: Aerosol Spray Can

NUMBER OF COATS: 2 - 3

DRY FILM THICKNESS PER COAT: 2 mils

APPLICATION TEMP: 50°F Min / 90°F Max

THINNER/CLEANER: 120 Brushing Thinner

DRY TIME: Minimum times

| | TO TOUCH (MINS) | TO HANDLE (HOURS) | TO USE (HOURS) |
|------|--------------------|----------------------|-------------------|
| 90°F | 10 | 1 | 6 |
| 70°F | 10 | 1 | 6 |
| 50°F | 20 | 2 | 10 |

The above dry times are minimums. EZ Fabriccoat™ may be recoated after the minimum time shown. Apply 2 or more light coats a few minutes apart.

ASSOCIATED PRODUCTS: Pettit 120 Brushing Thinner, Pettit 97 Epoxy Thinner

Shake the can of paint for one to two minutes after the mixing ball begins to rattle. Hold can 10-12 inches from surface. Depress nozzle and spray with smooth, even strokes. Shake often during use.

When done spraying, clean valve by spraying upside down for 2-3 seconds until no more paint comes out. Wipe off tip with 120 Brushing Thinner. If valve clogs, carefully remove spray tip and soak in thinner. Do not stick pins or sharp objects into can or valve.

Adhere to all application instructions, precautions, conditions and limitations to obtain optimum performance. Refer to individual labels and tech sheets for detailed instructions when using associated products, etc.



COATING PERFORMANCE, IN GENERAL, IS PROPORTIONAL TO THE DEGREE OF SURFACE PREPARATION. FOLLOW ALL RECOMMENDATIONS VERY CAREFULLY, AVOIDING ANY SHORTCUTS.

PAINTING CONDITIONS: Use outdoors or in a well-ventilated area. Use when temperature is between 50-90°F and humidity is below 85%. Do not apply to surfaces that, when heated, exceed 180°F. Avoid spraying in windy and dusty conditions. Cover surrounding areas to protect from spray mist.

SURFACE PREPARATION (VINYL, CARPET): Clean surface with warm soapy water, rinse and let dry. If surface was previously treated with conditioners, waxes or other coatings, additional cleaning is required, use Pettit 120 Brushing Thinner. It is important that all residual coatings be removed from vinyl surfaces prior to application.

SURFACE PREPARATION (RUBBERIZED FABRIC SURFACES, PVC): Wash the rubberized fabric surfaces to be painted with a mild detergent and water solution. Rinse thoroughly with copious amounts of clean, fresh water and allow to dry thoroughly. Pour a moderate amount of Pettit 97 Epoxy Thinner onto a bronze wood pad. Choose a small area on the surface to be painted and scrub the surface lightly but thoroughly, making sure the surface is completely wetted by the Pettit 97 Epoxy Thinner. Wipe off any excess Pettit 97 Epoxy Thinner with a clean rag before it is allowed to dry and repeat the process until the entire surface to be painted has been scrubbed and wiped clean. **NOTE:** If the Pettit 97 Epoxy Thinner is spilled or runs down the side of the inflatable, wipe up the spill or runs immediately. While the Pettit 97 Epoxy Thinner is generally safe on most surfaces, it may dull the gloss of paint or mar the surface of the inflatable if allowed to remain in contact with the surface. To facilitate the scrubbing process, the Pettit 97 Epoxy Thinner may be poured into a small container and the bronze wool pad dipped into it. Change the 97 Epoxy Thinner frequently to avoid using excessively dirty or contaminated material. Spent material should be disposed of, not reused. Once the surface to be painted has been properly prepared, apply 2 - 3 coats of EZ Fabriccoat. Consult the dry to recoat/dry to launch time-temperature chart above for specific recoat and use times. **DO NOT USE ON HYPALON.**

APPLICATION: Shake can vigorously for one minute after the mixing ball begins to rattle. If mixing ball fails to rattle DO NOT STRIKE CAN. Contact Pettit. Shake often during use. Hold can 10-12" from surface and spray in a steady back-and-forth motion, slightly overlapping each stroke. Keep the can the same distance from the surface and in motion while spraying. Apply 2 or more light coats a few minutes apart. **Do not use near open flame.**