

EZ PRIME

Multipurpose Topside Primer

- Versatile primer that easily hides imperfections for a smoother finish surface
- Easy one-art application cuts down on costs and labor
- High filling, fast covering formula cuts down on number of coats needed



PREMIUM HIGH-BUILD TOPSIDE UNDERCOATER

EZ-Prime 6149 is a multipurpose primer designed for use as a base coat whenever the surface to be painted is aged, cracked, checked, pitted, or in any way less than smooth. It can be applied to fiberglass, wood, properly etched metal, and previously painted surfaces. EZ- Prime fills imperfections fast, dries quickly, and is easy to sand. Its high-solids formula has excellent filling and covering properties that produce a smooth, prepared surface often times in just a one-coat application. **Not for use below the waterline.**

EZ-Prime can be tinted to better match the finish enamel so there is not such a striking contrast between the two colors.

TECHNICAL INFORMATION

VEHICLE TYPE: Oil Modified Alkyd
FINISH: Flat
COLOR: White
COMPONENTS: One
CURING MECHANISM: Air Dry/Oxidation
COVERAGE: 400 ft²/gal.
VOC: 395 grams/liter (*max*)
APPLICATION METHOD: Brush, roller, airless or conventional spray
FLASH POINT: 77°F
NUMBER OF COATS: One or Two

WET FILM THICKNESS: 3.8 mils
DRY FILM THICKNESS: 1.75 mils
APPLICATION TEMP: 50°F Min / 90°F Max
THINNER: 120 Brushing Thinner
 121 Spraying Thinner
DRY TIME: Minimum time in hours

	TO TOUCH	TO RECOAT
90°F	½ hr	1 ½ hr
70°F	1 hr	3 hrs
50°F	2 hrs	6 hrs

The above dry times are minimums.

ASSOCIATED PRODUCTS: D-95 Dewaxer, 92 Bio-Blue Hull Surface Prep, 120 Brushing Thinner, 121 Spraying Thinner, 6627 Tie Coat Primer, Pettit EZ Poxy, 7050 EZ Fair, 6980 Rustlok, 7050 EZ Fair, 2018 EZ Wood Sealer, 7100 EZ Tex, Pettit EZ Decks

All painting should be done between 9:00 a.m. and 4:00 p.m. in order to avoid the possibility of dew or condensation spoiling the application with temperatures ranging between 50°F to 90°F. When working in cooler temperatures be sure the air and surface temperatures will remain at or above 50°F for at least 8 hours after application. Do not apply this product with high humidity or with weather threatening. Stir thoroughly before use. 6149 EZ-Prime may be applied by brush, roller, conventional, or airless spray. For brush or roller application apply without thinning, although in hot weather 5-10% Pettit 120 Brushing Thinner may be added to help maintain a wet edge. Do not thin more than 10% (12 ounces per gallon) when applying by brush or roller or inadequate paint film thickness will occur. For best results on large, smooth surfaces roll out using a short nap or foam roller followed immediately by leveling off with the tip of a brush. For conventional spray application thin 15-20% with Pettit 121 Spraying Thinner. For airless spray application thin up to 5% with Pettit 121 Spraying Thinner. Utilize a .011-.015 inch diameter tip for application. Do not thin beyond your state's compliant limit.



After four hours dry time, lightly sand with 150 grit sandpaper and apply a second coat, if necessary. Always wipe with a tack cloth immediately before the fresh application of paint to remove any airborne dust which may have settled. Applying three or more coats in one day or applying excessively heavy films (greater than 5 wet mils) will lead to insufficient through drying of the paint and will yield soft paint films.

SURFACE PREPARATION: Coating performance, in general, is proportional to the degree of surface preparation. Follow recommendations carefully, avoiding shortcuts. Inadequate preparation of surfaces will virtually assure inadequate coating performance. Surface must be free of dirt, loose paint, rust, oil, grease, wax, soap and any other foreign matter. Clean painted areas by washing with a solution of 2 cups household ammonia per gallon of water and rinse well. Remove existing mildew with household bleach instead of ammonia.

WOOD: Sand surface smooth with 80-120 grit sandpaper, then solvent clean with Pettit 120 Thinner to remove residue. Fill all screw heads, nicks, gouges, and small holes with 7050 EZ-Fair Epoxy Fairing Compound; sand flush and solvent clean with Pettit 120 Thinner. Apply a coat of 2018 EZ Wood Sealer to penetrate and seal the porous grain. Follow with one or two coats of 6149 EZ Prime until an evenly smooth base condition is reached; sand each coat with 120 grit sandpaper and solvent clean with Pettit 120 Thinner. Proceed with the first finish coat of Pettit topside paint.
Bare wood that has been epoxied must be thoroughly scrubbed with an ammonia/water solution then sanded with 120 grit sandpaper and solvent cleaned with Pettit 120 Thinner. If the surface is too rough or heavy imperfections exist, it will have to be repaired. Fill all deep nicks and gouges with 7050 EZ-Fair Epoxy Fairing Compound; sand flush when hard, then solvent clean. Follow with one or two coats of 6149 EZ Prime to smooth the surface and provide a uniform base. Sand well and solvent clean with Pettit 120 Thinner, then proceed with the first coat of Pettit topside paint.

FIBERGLASS: The entire surface to be painted regardless of age must be thoroughly washed with #92 Bio-Blue Hull Surface Prep or wiping several times with Pettit 120 Thinner to remove all traces of mold release agents and wax. For best results, clean and prep the surface using Pettit #92 Bio-Blue Hull Surface Prep and a Scotch-Brite pad. Thoroughly rinse the surface and allow to dry. Remove any remaining residue by wiping the surface with Pettit 120 Thinner. Sand the gel coat with 120 grit sandpaper to a dull, frosty appearance, solvent clean with Pettit 120 Thinner to remove residue. Proceed with one or two coats of 6149 EZ Prime until an evenly smooth base condition is reached; sand each coat with 120 grit sandpaper and solvent clean with Pettit 120 Thinner. If the surface is too rough or heavy imperfections exist, it will have to be repaired. Fill all deep nicks and gouges with 7050 EZ-Fair Epoxy Fairing Compound; sand flush when hard, then solvent clean with Pettit 120 Thinner, then proceed with one or two coats of 6149 EZ Prime until an evenly smooth base condition is reached; sand each coat with 120 grit sandpaper and solvent clean with Pettit 120 Thinner. Proceed with the first finish coat of Pettit topside paint.

ALUMINUM: Clean and prep the surface using Pettit #92 Bio-Blue Hull Surface Prep and a Scotch-Brite pad. Thoroughly rinse the surface and allow to dry. Remove any remaining residue by wiping the surface with Pettit 120 Thinner. Remove oxidation and etch the surface with medium grit emery cloth; remove sanding residue. Apply one thin "wet" coat of 6980 Rustlok, allow to dry tacky. Proceed with one or two coats of 6149 EZ Prime to smooth the surface and provide a uniform base. Sand well and solvent clean with Pettit 120 Thinner, then proceed with the first coat of Pettit topside paint.

STEEL: Surface must be cleaned to a bright finish by sandblasting or grinding; remove blast residue. Immediately apply one coat of 6980 Rustlok Primer; allow to dry until tacky. If surface is rough, apply a coat of 6627 Tie-Coat Primer; sand well and solvent clean with Pettit 120 Thinner. Repeat application as needed until surface is no longer rough. Proceed with one or two coats of 6149 EZ Prime to smooth the surface and provide a uniform base. Sand well and solvent clean with Pettit 120 Thinner, then proceed with the first coat of Pettit topside paint.

PAINTED SURFACES: Clean and prep the painted areas using Pettit #92 Bio-Blue Hull Surface Prep using a Scotch-Brite pad or stiff bristle brush. Thoroughly rinse the surface and allow to dry. Remove existing mildew with household bleach. Never mix bleach and ammonia. If the old paint is an oil-based enamel or polyurethane, and is in good, sound condition, sand it thoroughly smooth with 150 grit sandpaper, solvent clean to remove residue with Pettit 120 Thinner, then proceed with one or two coats of 6149 EZ Prime until an evenly smooth base condition is reached; sand each coat with 120 grit sandpaper and solvent clean with Pettit 120 Thinner. If the surface is too rough or heavy imperfections exist, it will have to be repaired. Fill all deep nicks and gouges with 7050 EZ-Fair Epoxy Fairing Compound; sand flush when hard, then solvent clean with Pettit 120 Thinner, then proceed with one or two coats of 6149 EZ Prime until an evenly smooth base condition is reached; sand each coat with 120 grit sandpaper and solvent clean with Pettit 120 Thinner. Proceed with the first finish coat of Pettit topside paint. If the old paint is a latex or water-based paint, or is in poor condition, remove it with a paint remover or by sanding. Proceed with instructions for the appropriate bare surface system.

COATING PERFORMANCE, IN GENERAL, IS PROPORTIONAL TO THE DEGREE OF SURFACE PREPARATION. FOLLOW ALL RECOMMENDATIONS VERY CAREFULLY, AVOIDING ANY SHORTCUTS.